
# GOBI ASSEMBLY INSTRUCTIONS

Work mode. Wait mode. Let's-get-it-done mode. Today's open and collaborative spaces should help you shift spontaneously. And Gobi is the perfect huddle partner. Its sculpted comfort and modern, easy going design can carry you through the many modes you find yourself in—so that another day at the office feels like anything but.



# **GOBI ASSEMBLY INSTRUCTIONS**

### **COMPONENT LIST**


#### **Metal Base**

- Seat Assembly (1)
- Metal Mechanism (1)
- Cylinder (1)
- Metal Base (1)


#### **Wood Base**

- Seat Assembly (1)
- 5/16" × 1" Screw (2)
- 5/16" × 1 1/4" Screw (2)
- 5/16" Washer (4)
- Spacer (2)
- Wood Base (1)

### **REQUIRED TOOLS**




#### **COMPONENTS**





#### **METAL MECHANISM**


(Mechanism will come attached to seat.)



#### **BASE**







Spacers

### 1:1 SCALE











5/16" Washers

5/16" Washer

## **GOBI ASSEMBLY INSTRUCTIONS**


Base Assembly

Cylinder

Seat Assembly

Mechanism

SUGGESTED ORIENTATION






#### **STEPS**


1. Slide the cylinder into the center of the base assembly and give it a push to seat it into position. With the seat assembly sitting upside-down on the floor, firmly hold the base assembly, align the top of the cylinder with the mechanism's cylinder mounting hole and push in place until seated. The cylinder is seated when you can lift the chair and the cylinder stays attached to the mechanism.

Note: For auto-return cylinders, the position in which the chair is first placed will be the "return" position.


# **GOBI ASSEMBLY INSTRUCTIONS**

#### 1 WOOD BASE OPTION





2





#### **STEPS**

- 1. With the seat assembly sitting upside-down on the floor, place one spacer over each of the front holes on the seat assembly. Firmly hold the base assembly and align it with the hole pattern of the seat assembly.
- 2. Slide one 5/16" washer over each of the four screws, then thread the two 5/16" x 1 1/4" screws through the holes with spacers, and the two 5/16" x 1" screws through the remaining two holes. Tighten all four screws using a 1/4" hex L-key.